

TrainBoss™ Defect Detector

Talking Detector | Model No. TB-23F (Female Voice)
For 1 or 2 Tracks | Model No. TB-23M (Male Voice)

Hotbox & Equipment Defect Detector for model railroads

- For **One Track** (reports axle count, speed, length & total axles per session), or **Two Tracks** (double track or two single tracks, reports axle count & total axles), or **Clearance Zone** (protects around bridges, tunnels – reports axles & total axles)
- Voice report or visual display configurations to match your railroad era:
 1. Modern **male or female automated trackside** voice reports (1980s – Today)
 2. **Trackside and remote operator displays** (1940s – Today)
 3. **Train crew** voice reports (all eras)
- Speaks/displays 6 types of defect alarms for passing trains: hotbox, dragging equipment, high car, wide or shifted load, sliding wheel
- **User defined** voice reports to match your prototype, **120+ built-in words/phrases**
- **User defined** alarm probability for each defect type, 1/30 to 1/8000 cars
- Infrared Axle Sensors support day and night operation in all scales
- Volume-controlled speaker output and stereo jack for powered speakers
- 200 mA alerting outputs drive LEDs, motors, relays, or other railroad electronics
- Inputs to 1) Repeat last message, 2) Force alarm on next train, 3) Clear alerts

Simple installation

- One-piece Axle Sensors slip under installed track and simplify correct alignment
- Screw terminals for all circuit board connections
- Factory configured for immediate use
- Power Supply: DC (9-12 V) or AC (7-9 V), 250 mA **required**
- 8-Ohm speaker or powered speakers **required**

Parts List

- **TrainBoss™ Defect Detector** Circuit Board
- Infrared Axle Sensors (2)
 - Fascia Template
- Report Push Button Switch
 - Vinyl Tubing for Standoffs

Notice: This product simulates defect detection for model railroads and does not sense the true condition of rail cars.

Before You Install

- Your **TrainBoss™ Defect Detector** is damaged by static electricity. Before touching the circuit board, discharge static by touching a bare metal surface.
- Do not install or make connections when circuits or track are powered.
- Insulate all exposed connections, preferably with heat shrink tubing.
- Prevent contact between Defect Detector and track wiring. **DCC will damage it.**
- Read through the rest of these instructions before beginning.
- Visit www.bouldercreekengineering.com for additional information.

1. Selecting Installation Options

Your **TrainBoss™ Defect Detector** can function as **one** or **two** Defect Detectors, and can protect close clearance structures. **Figure 1** compares these three options.

Choose your installation option before installing. See **Section 9**, SV 15.

Single Detector Option (SDO) (Set SV15, Bits 7, 6 to **0 0**)

The **Single Detector Option (SDO)** is the standard configuration for the Defect Detector as delivered from the factory. In this configuration, the two Axle Sensors are installed on one track within 235 scale feet of each other. This allows complete reporting of axle counts, train speed, and train length. **SDO** is the best match for modern talking defect detectors.

Double Detector Option (DDO) (Set SV15, Bits 7, 6 to **1 1** or **1 0**)

The Defect Detector acts as two independent talking defect detectors in the **Double Detector Option (DDO)**. These independent detectors report axle counts, but do not report speed or length of passing trains.

In the **Double Detector Option**, each Axle Sensor is installed on a separate track driving its own defect detector circuit. The “W” Axle Sensor drives Detector 1 and LED Output 1 from its location, and reports with message headers 1, greeting 1, and close 1. The “S” Axle Sensor drives Detector 2 and LED Output 2 from its location, and reports with message headers 2, greeting 2, and close 2.

The Axle Sensors can be on adjacent double track main line as shown in **Figure 1**, or on single track many scale miles apart. Connect each Axle Sensor to the Defect Detector circuit board with less than 100 feet of wire.

Clearance Zone Option (CZO) (Set SV15, Bits 7, 6 to **0 1**)


On prototype railroads, close clearance structures such as bridges and tunnels are often protected by talking defect detectors from high, wide, or shifted loads. Configure your Defect Detector to guard a close clearance zone with the **Clearance Zone Option (CZO)** as shown in **Figure 1**. **CZO** does not report train speed or length.

In **CZO**, the first Axle Sensor to detect a passing train is the active sensor for that train and drives the report – the second detector does not report. When active, the “W” Axle Sensor reports with message headers 1, greeting 1, close 1; the “S” Axle Sensor reports with headers 2, greeting 2, and close 2.

The Defect Detector immediately reports defects and drives LED Outputs. This gives time to stop a train before reaching the structure.


After both Axle Sensors are inactive for the time set by the Axle Sensor Time Out (SV 7), the Defect Detector is ready for the next train. If a short train takes more than the Axle Sensor Time Out to reach the second detector after a report, there will be a second report. If a passing train stops and blocks an Axle Sensor, a "Sensor Blocked" message is given.

In **CZO**, the Axle Sensors can be any distance apart, and should be located far enough from the structure to allow defective trains to stop. We suggest installing Axle Sensors at least one half your longest train length from the close clearance structure. Connect each Axle Sensor to the Defect Detector circuit board with less than 100 feet of wire.




Single Detector Option (SDO)

- Two Axle Sensors on One Track
- Axle Sensors 20 – 235 Scale Ft. Apart
- Reports Axle Count, Speed, Length
- Direction Determined Messages (See SV 16 & 17, Bit 5)



Double Detector Option (DDO)

- One Axle Sensor on Each of Two Tracks
- Tracks can be Double Track as shown, or Single Tracks scale miles apart
- Each Axle Sensor can be up to 100 Actual Ft. from the Circuit Board
- Reports Axle Count Only



Clearance Zone Option (CZO)

- Protects Close Clearance Structures from wide, high, or shifted loads
- **Immediate** Alarm on any Defect
- Two Axle Sensors on One Track
- Axle Sensors Any Distance Apart
- Reports Axle Count Only

Figure 1: Installation Options

2. Installing Axle Sensors

Only one Axle Sensor is needed for your **TrainBoss™ Defect Detector** to produce alarms in the **Single Detector Option (SDO)**. Add the second sensor for **DDO** or **CZO**, or for train speed and length reports in **SDO**.

1. Select the location for your Axle Sensors. A straight section of track avoids interference problems for long rail cars on curves.

Close incandescent lighting will interfere with proper Axle Sensor operation. **40 W bulbs within 12 inches will block proper detection.**

2. If you are installing two Axle Sensors for **SDO**, install them 4 to 235 scale feet apart. Over 20 scale feet is recommended. (The factory setting is 44 scale feet; change SV 7 if you choose another spacing.)

You can install Axle Sensors before or after installing your track. Refer to either Step 3 or Step 4 to match your situation.

3. Installing the Axle Sensor before installing the track:
 - a. Refer to **Figure 2** for correct Axle Sensor positioning for your scale.
 - b. Carefully bend the Axle Sensor's LED to face the Infrared Sensor.

Warning: Bending the LED more than once can break the LED.

- c. Position the Axle Sensor, mark and drill a 3/16" hole for the wires through the roadbed.
- d. Thread the wires through the hole.
- e. Remove ties as necessary and lay the track over the Axle Sensor.
- f. Go to Step 5.




Figure 2: Axle Sensor Alignment

4. Installing the Axle Sensor after installing the track:

- a. Power down your track.

Warning: Installing while track is powered will damage the Detector.

- b. Refer to **Figure 2** for correct Axle Sensor positioning for your scale.
- c. Remove ties from the track as necessary.
- d. Drill a 1/4" hole in the roadbed beneath the track and partially or completely across the rails as in **Figure 2**.
- e. Cutting with a knife, extend the roadbed hole to the roadbed surface.
- f. Position the Axle Sensor, mark and drill a 3/16" hole for the wires through the roadbed.
- g. With the LED leading, slide the Axle Sensor under the rail(s).
- h. Thread the wires through the 3/16" hole.
- i. Carefully bend the Axle Sensor's LED to face the Infrared Sensor.

Warning: Bending the LED more than once can break the LED.

- 5. Align the LED to just clear the top of the rail as in the "HO Scale Cross Section" of **Figure 2**. Check that rail cars clear the Axle Sensor.
- 6. We will test the Axle Sensor(s) later in the installation. Do not glue Axle Sensors in place until your installation is complete and tested.

3. Choosing a Configuration

Your **TrainBoss™ Defect Detector** can be configured to match one of three operating eras. Two eras feature voice reports, while the third era offers two visual display choices. All era configurations work with the **Single Detector (SDO), Double Detector (DDO) and Clearance Zone (CZO) Options** described in **Section 1**. Choose your era configuration before installing.

Automated Trackside Voice Reports (1980s – Today)

This configuration simulates today's defect detector reports heard on radio scanners. Your Defect Detector can be customized to match a prototype. Each passing train receives a voice message with train status or a defect alarm. Pressing the **Report** push button repeats the last message.

Male or female voice is set by the voice chip on your **TrainBoss™ Defect Detector** Circuit Board – see **Figure 5**. Voice chips labeled with M are male; chips labeled with F are female. Voice chips are available on our website (www.bouldercreekengineering.com) if you want to change voices.

As shown in **Figure 3**, the Defect Detector circuit board is mounted on benchwork below the roadbed and near the Axle Sensors and speakers.

For this configuration, continue with **Section 4, Installing the Circuit Board**.

Train Crew Voice Reports (all eras)

Traditionally, train crews kept a look out for equipment defects from the engine cab and caboose. They alerted the engineer to stop the train (using an air whistle from the caboose if necessary) and then met to talk over the problem and a fix. In this configuration, your Defect Detector sounds two short whistles to stop the train. The **Report** push button starts the report.

As in the previous configuration, the Defect Detector circuit board is mounted near the Axle Sensors and speakers as shown in **Figure 3**.

For this configuration, continue with **Section 4, Installing the Circuit Board**.




Figure 3: Voice Report Installation

Trackside or Remote Visual Display (1940s – Today)

Starting in the 1940s, railroads began to automate train defect detection before recorded voice reporting was available.

For this configuration, please visit www.bouldercreekengineering.com and follow the **Installing TrainBoss™ Talking Defect Detector for Display Only** guide on our Manuals page.

4. Installing the Circuit Board

Mount the **TrainBoss™ Defect Detector** circuit board under your layout near the Axle Sensor(s) as shown in **Figure 4**. Slice 1/4" standoffs from the vinyl tubing provided. The screw holes in the circuit board are for No. 4 pan-head screws (not included).

Warning: Do not enlarge the circuit board holes or over-tighten the mounting screws as this will damage the circuit board.




Figure 4: Circuit Board Installation

5. Wiring Instructions

Figure 5 shows how to wire your **TrainBoss™ Defect Detector** for voice reporting, along with key features on the circuit board.

1. Connect two wires from your power supply to the Defect Detector power **gray** terminals as shown in **Figure 5**. Polarity does not matter. The power supply must be 7 to 9 Volts AC or 9 to 12 Volts DC, with 250 mA capacity. Radio Shack sells an AC adapter (#273-314) that works well.

Warning: Do not exceed 9 Volts AC or 12 Volts DC as this will damage the circuit board.

Warning: Do not share an AC Adaptor with other electronics as this will lead to humming or buzzing interference in the audio output.

2. Connect the RED, BLACK and YELLOW wires from the Axle Sensors as shown in **Figure 5**.
3. If you are installing both Axle Sensors, **remove Jumper J9**.
4. You can wire Alerting LEDs to the LED Outputs as in **Figure 5**. LEDs are polarity sensitive – connect the long and short leads as shown. Visit

www.bouldercreekengineering.com/manuals.php for information on how to interface other electronics to these two outputs. (LEDs not included.)

5. A **Report** Switch triggers or repeats a defect report. Connect the push button **Report** Switch (included) as shown in **Figure 5**. Connect extra **Report** switches (n. o. type) between **R** and **G** if desired.
6. The **Next Train** Switch forces a defect report on the next train when pressed, which is nice for testing. If desired, connect a push button **Next Train** Switch (n. o. type – not included) as shown in **Figure 5**.
7. Grounding **Clear Outputs** will clear LED Outputs 1 and 2. Visit our website (www.bouldercreekengineering.com/manuals.php) for information on how to interface other electronics to this input.
8. Connect either an 8 ohm speaker to the **SPEAKER** terminal block or connect powered speakers with a 1/8" stereo plug to the **LINE** jack. Powered speakers are highly recommended as they provide much better sound quality and are available for about \$10 from Amazon and other Internet sources. (**Speakers are not included.**)

Warning: Connecting a speaker rated less than 8 ohms to the SPEAKER terminal block will damage the circuit board.




Figure 5: Circuit Board & Wiring Diagram

6. Testing Your Installation

1. Apply power to your **TrainBoss™ Defect Detector**. The Heartbeat LED should blink once every second. Check your power wiring if it does not.
2. Axle Sensor LEDs should be off. Check Axle Sensor alignment if not.
3. For **DDO** or **CZO**, program SV15, Bits 7, 6 as instructed in **Section 9**. Continue testing your installation by testing **both** Axle Sensors as directed for the “W” Axle Sensor in Steps 4 - 6 below. Ignore testing of the “S” Axle Sensor in Step 7.
4. Set the 3-Way Mode Switch to “A”.
5. Break the infrared beam(s) by passing your finger along the track. The Axle Sensor LEDs should flicker. Check your wiring if they do not. You will hear an automated voice report in a few seconds.
6. Repeat Step 5 by running a train. If axle count is correct, glue your “W” sensor in place. **Allow 48 hours for water-based glue to thoroughly dry before connecting to your Defect Detector.**
If axle count is not correct, check the alignment of the “W” Axle Sensor. The infrared beam should just clear the railhead as in **Figure 2**.
7. If you receive a speed and length report, glue your “S” sensor in place. Be sure to program SV 7. (See **Section 9**).
If you do not receive a speed or length report, check the alignment of the “S” Axle Sensor. The infrared beam should just clear the railhead as in **Figure 2**. Also check your wiring.
8. **Congratulations**, your Defect Detector is now operational!

7. Basic Operation

7.1 Operating Modes and Mode Switch Positions

The 3-way Mode Switch positions are labeled S, A, and C. See **Figure 5**. Changing the switch position immediately puts the Defect Detector into a new mode:

S = SETTINGS – Settings Mode (See **Section 8**)

A = AUTOMATED – Automated Trackside Voice Reports Mode (See **Section 7.2**)

C = CREW – Train Crew Voice Reports Mode (See **Section 7.3**)

The Defect Detector Circuit Board has a green “Heartbeat LED” that blinks every second while waiting for a train in **A** or **C**. It is steadily on other times.

The red “Speaking LED” flashes when the Detector is speaking messages.

7.2 Automated Mode Operation

With the 3-Way Mode Switch in the **A** position, the Defect Detector will speak an automated message 5 seconds after a train passes. If all is well, status is spoken, which may include axle count, speed, and train length. Otherwise, a defect type and axle are spoken. Push the **Report** Push Button to repeat.

The **Report** Push Button repeats only the last spoken report. Once a new train triggers a new report, the previous report can no longer be played. In **DDO**, time between trains can be brief – too short to repeat the first report.

7.3 Crew Mode Operation

With the Mode Switch in the **C** position, the Defect Detector will speak as a train crew member (with railroad slang) 5 seconds after a train passes. If all is well, an “all clear” is given. Otherwise the crew gives two toots on the air whistle to stop the train. (This is per Rule 16b in the Consolidated Operating Rules.) Pushing the **Report** Push Button will start or repeat the report. Only hot boxes, dragging equipment and speed warnings are reported.

The **Report** Push Button repeats only the last spoken report. Once a new train triggers a new report, the previous report can no longer be played. In **DDO**, time between trains can be brief – too short to repeat the first report.

7.4 Displayed Information

While speaking, the Defect Detector will also briefly display axle count, speed, length, and temperature – in that order – if there are no defects. In case of a defect, a one letter defect code is given as shown in the following table, along with the axle location. **Figure 6** shows a Hotbox on axle 120, north or east rail.

Letter	Defect Type
X	Hot box
D	Dragging Equipment
S	Sliding Wheel
H	High Car
W	Wide Load
L	Shifted Load




Figure 6: Axle 120 Hotbox, with north or east rail indicated by decimal point

7.5 Volume Adjustment

To increase or decrease speech sound volume, press SELECT with the 3-Way Mode Switch in the **A** or **C** position while waiting for a train. There are eight volume levels; each push of SELECT moves volume incrementally up to the maximum, then down to the minimum, then back up again.

For powered speakers, set your Defect Detector to a medium volume and make final volume adjustments with the speaker controls.

7.6 Error Messages (See SV 18, Bit 7 in Section 9)

Spoken Message	Display	Meaning
"Malfunction" or "Integrity Error"	*ERR	Starting/stopping/reversing trains close to the Axle Sensors has reset the Detector
"Sensor Blocked"	*DET	An Axle Sensor is blocked by a railcar after a report, or upon power up or reset

8. Settings Mode Operation

8.1 Settings Mode Basics

While your **TrainBoss™ Defect Detector** works right out of the box, you can customize its performance by changing the values of its Setting Variables (SVs). SVs are similar to Configuration Variables (CVs) for DCC decoders. SVs set up the voice messages for passing trains, determine the behavior of connected LEDs, and set the average number of cars between defects. There is even an SV that turns on or off railroader slang in train crew reports! **Section 9** describes the SVs available for your Defect Detector.




Figure 7a: Entering Settings Mode. SV 1 is displayed with decimal point to the right. No value shown while navigating among SVs.




Figure 7b: SV with its stored value. SV 1 has a stored value of 10. Stored value is indicated with decimal point to the right of the value.




Figure 7c: SV with unstored value. Pressing UP jumps the value from 10 to 12 as 11 is not a valid value for this SV. (See **Section 9**, Setting Variable Descriptions.) No decimal point to right of 12 indicates it is not a stored value.




Figure 7d: SV with new stored value. Selecting this unstored value will store it, and a decimal point appears to its right indicating it is the stored value.

Upon selecting **S** with the 3-way Mode Switch, the Defect Detector enters Settings Mode and will show SV 1, but not a value, on the Display. See **Figure 7a**. Axle Sensors are ignored while in Settings Mode.

While in Settings Mode, the Display shows the number of the current SV, followed by a decimal point. (See **Figure 7a**.) A value for an SV is shown to the right of this decimal point. (See **Figure 7c**.) If this value is the currently stored value for the SV, there is another decimal point to the right of the value. (See **Figures 7b** and **7d**.) Selecting either the **A** or **C** position on the 3-way Mode Switch will exit Settings Mode. The Defect Detector will immediately begin operation.

8.2 Navigating SVs

1. Use the Navigation pushbuttons (UP, DOWN, SELECT, BACK – see **Figure 5**) and the Display to move among SVs. A light touch is best.
2. Use UP and DOWN to move forward and backward among SVs.
3. Holding down the UP and DOWN pushbuttons will move rapidly through SVs in the direction indicated.
4. UP and DOWN pushbuttons “wrap around” between the highest and lowest SV. Unused SVs are skipped.
5. To show the more than 100 SVs in just two digits, SVs higher than 99 use letters. For example, 98, 99, A0, A1, and A8, A9, B0, B1, and so on.
6. Pressing the SELECT pushbutton stops navigation among SVs and displays the stored value of the displayed SV. SV value can now be changed as described in “Changing SV Values” below. See **Figure 7b**.
7. Returning the 3-way Mode Switch to **A** or **C** position exits Settings Mode.

8.3 Changing SV Values

1. When the SV value is displayed, use the four pushbuttons (UP, DOWN, SELECT, BACK) and the Display to select a value for the current SV.
2. Use UP and DOWN to increase or decrease the displayed SV value. See **Figures 7b** and **7c**.
3. Holding down UP and DOWN pushbuttons will move rapidly through values in the direction indicated.
4. UP and DOWN pushbuttons “wrap around” between the highest and lowest value. Unused SV values are skipped.
5. Pressing the SELECT pushbutton will store the displayed value for this SV. **A decimal point appears to the right of the value to indicate it is the new stored value.** See **Figure 7d**.

- 6. Pressing the BACK pushbutton will stop display of values and return to navigating SVs as described above. See **Figure 7a**.
- 7. Returning the 3-way Mode Switch to **A** or **C** position exits Settings Mode.

8.4 Bit-Wise SV Values

SVs 11 through 18 turn features on or off by storing a one or zero in a particular bit position. See SV 15 for a good example.

To avoid fancy arithmetic, these bit-wise SVs have an additional level of navigation. See **Figure 8**. Here it is step by step:

- 1. Navigate to the desired SV with UP and DOWN. See **Figure 8a**.
- 2. Press SELECT. The Bit Number is displayed. See **Figure 8b**.
- 3. Navigate to the desired Bit Number (UP, DOWN). See **Figure 8c**.
- 4. Press SELECT. The Bit value is displayed. See **Figure 8d**.




Figure 8a: Navigate to desired SV.
SV 15, our target, is displayed. Compare to **Figure 8a**.




Figure 8b: Bit Number displayed.
SELECT causes Bit Number to display with decimal point to its right. Bit 0 is the first Bit Number displayed.




Figure 8c: Navigate to desired Bit.
UP and DOWN are used to navigate to our target, Bit 2. This bit turns on the Visual Display of messages.




Figure 8d: Current Bit value.
SELECT causes Bit value to display. "1" is the current stored value – Visual Display is on.




Figure 8e: New stored Bit value.
UP/DOWN move back and forth between "0" and "1" Bit values. SELECT stores value of "0" – Visual Display is off.

- 5. UP and DOWN will move the Bit value between 0 and 1. Press SELECT to store the displayed value. See **Figure 8e**.
- 6. BACK will stop display of Bit values and return to navigating Bit Numbers. See **Figures 8b** and **8c**.

8.5 Returning to Factory Default

While in Settings Mode, you can return your Defect Detector SVs to their original values:

- 1. While navigating SVs, depress and hold the BACK pushbutton.
- 2. While holding down BACK, depress and hold down both the UP and DOWN pushbuttons at the same time.
- 3. After 4 seconds, the Defect Detector will show *RST and say "Reset".
- 4. Release all three pushbuttons. All SVs are now reset to original values.

8.6 Viewing Session Axle Count

While in Settings Mode, you can view total axles counted since power on:

- 1. While navigating SVs, depress and hold the BACK pushbutton.
- 2. While holding down BACK, depress and hold down the SELECT pushbutton at the same time.
- 3. After 4 seconds, the Defect Detector will show and say the total axles since power up. The Detector will count up to 4095, then roll over to 0.
- 4. Release both pushbuttons to return to navigating SVs.

9. Setting Variable (SV) Descriptions

Visit our website (www.bouldercreekengineering.com/manuals.php) for worksheets to record your SV settings.

Some SVs are only valid for the **Single Detector Option (SDO)** or the **Clearance Zone Option (CZO)** as noted. SVs are ignored if they are invalid for the option selected by SV 15, Bits 7 and 6.

SV 1 – 6: Defect Probabilities

Description: The average number of 4-axle cars per defect. Value stored and displayed is 1/10 of the actual rate, so multiply by 10 for the true value.

If more than one defect type is on, the defect occurrences will add. For example, if both Hotbox and Dragging Equipment are set to 100 (10 stored), you could expect one of each defect type every 100 cars, or a defect of either type roughly every 50 cars or so.

Valid Values: 0 (defect disabled), 3, 4, 5, 6, 8, 10, 12, 15, 20, 25, 30, 40, 50, 60, 80, 100, 120, 150, 200, 270, 400, 800

Examples: 3 = 30; 10 = 100; 800 = 8000 average cars per defect

SV	Defect Type	Default
1	Hotbox	10 (=100)
2	Dragging Equipment	0 (disabled)
3	Sliding Wheel	0 (disabled)
4	High Car	0 (disabled)
5	Wide Load	0 (disabled)
6	Shifted Load	0 (disabled)

Note: This probability is an average. For example, with the default setting and after 5000 cars have passed, you would expect to have seen about 50 hotboxes. But just as in real life, you can't predict when stuff will happen!

SV 7: Axle Sensor Separation SDO Only

Description: The distance in scale feet between the two Axle Sensors.

Valid Values: 4 – 235, minimum of 20 suggested

Default Value: 44 scale feet

Examples: 89 scale ft. between sensors; 126 scale ft. between sensors

SV 7: Axle Sensor Time Out CZO Only

Description: The time in seconds that both Axle Sensors must be idle before detector is ready for the next train. Set to a time longer than it takes the shortest train to travel between sensors to avoid triggering a report when passing the second sensor.

Valid Values: 4 – 235, minimum of 10 suggested

Default Value: 44 seconds

Examples: 15 seconds, 30 seconds before detector resets for next train

SV 8: Engine Axles

Description: Engine axles on front of train. Defects will not be assigned to these axles during normal operation – and avoided if possible for a “Next Train” event – if SV 15, Bit 4 is active.

Valid Values: 4- 235

Default Value: 8 axles

Examples: 4 axles, 12 axles, 18 axles

SV 9: Temperature

Description: The average temperature in Automated Voice Report Mode. Temperature will randomly vary +/- 4 degrees around this value and change only slightly from train to train.

Valid Values: 4– 235 (keep it real!)

Default Value: 50 degrees

Example: 32 degrees will produce a range of 28 – 36 degrees

SV 10: Speed Limit SDO Only

Description: The speed limit in MPH for this section of track. Trains traveling too fast or slow will trigger crew comments in Crew Mode operation only. The crew will signal the engineman to stop the train if the speed is more than 20 MPH over this value.

Valid Values: 4 - 99

Default Value: 40 MPH

Examples: 15 MPH, 45 MPH, 59 MPH

SV 11,12: LED Output Behavior

Description: Defines Output 1 and Output 2 behavior with individual bits.

Outputs are **on** or **off**. Outputs are either pulled to ground or open circuit when **on** and **off** as set by Bit 2.

- SV 11 controls Output 1
- SV 12 controls Output 2

Default Value: 01000010

Bit 7	6	5	4	3	2	1	Bit 0
Opp 1^a	Clr Rpt	ClrTime	DbtTime^b	Dir Sense^c	Invert	Output Action	

Bit 7 **Opposite Output 1 – SDO & CZO Only** (Ignored in DDO)

^aValid for SV 12 Output 2 only, ignored for SV 11 Output 1

1 = Output 2 puts out opposite value of Output 1, **off** if Output 1 is **on** and vice versa. The rest of this SV is ignored.

0 = Output 2 is independent of Output 1 and the rest of this SV determines Output 2 behavior (**default**)

Bit 6 **Clear on Report**

1 = Output is cleared to **off** when **Report** input activated (**default**)

0 = Output is not cleared to **off** when **Report** input activated

Bit 5 **Clear on Time**

1 = Output is cleared to **off** after time set by Bit 4

0 = Output is not cleared to **off** after time set by Bit 4 (**default**)

Bit 4 **Double Time**

^bValue in SV 11 applies to both Output 1 and 2; ignored in SV 12

In **CZO**, time starts after Detector is ready for next train – see SV 7.

1 = Output is cleared after 60 seconds

0 = Output is cleared after 30 seconds (**default**)

Bit 3 **Direction Sense – SDO & CZO Only** (Ignored in DDO)

^cValue in SV 11 applies to both Output 1 and 2; ignored in SV 12

1 = Output 1 driven if “W” Sensor triggers first; Output 2 if “S” is first

0 = Outputs both driven regardless of sensor trigger order (**default**)

Bit 2 **Invert**

1 = Output pulled to ground when **off**, open circuit when **on**

0 = Output open circuit when **off**, pulled to ground when **on** (**default**)

Bits 1, 0 **Output Action**

11 = Flash **on/off** when train has defects, patterned by SV 13/14

10 = **On** steady only when train has defects (**default**)

01 = **On** steady only when train has no defects

00 = **On** steady when train has no defects or output is cleared

SV 13,14: LED Output Flash Pattern

Description: Defines Output 1 and Output 2 flash patterns.

Corresponding Output Behavior SV must be set to Flash. Each bit turns the output **on** or **off** for 1/8 of a second, with 1 = **on** and 0 = **off**. Bit 0 controls the first 1/8 sec, Bit 1 the second 1/8 sec, etc. Pattern repeats every second.

- SV 13 controls Output 1
- SV 14 controls Output 2

Default Value: 00001111 (on ½ sec, off ½ sec)

Example: 01010101 is **on/off** 4 times per second

SV 15: Control 1

Description: Defines miscellaneous control values with individual bits.

Default Value: 00011100

Bit 7	6	5	4	3	2	1	Bit 0
Install Options	Max Defects	No Eng	Display	Round	Rnd Up		

Bits 7, 6 **Installation Options** (See Section 1.)

11 } = Double Detector Option (**DDO**) reports axles only

10 }

01 = Clearance Zone Option (**CZO**) reports axles only

00 = Single Detector Option (**SDO**) reports axles, speed, length (**default**)

Bits 5, 4 **Maximum Defects per Train**

11 = **3** maximum defect per train

10 = **2** maximum defect per train

01 = **1** maximum defect per train (**default**)

00 = defects will not be reported

Bit 3 **No Engine**

1 = Engine axles will not receive defects per SV 8 (**default**)

0 = Engine axles can receive defects

Bit 2 **Visual Display Enable**

1 = Messages always visually displayed (**default**)

0 = Message displayed only when **Report** push button depressed

Bit 1 **Round Odd Axle Counts**

1 = Odd axle counts rounded to be always even

0 = Odd axle counts not rounded (**default**)

Bit 0 **Round Up Odd Axle Counts**

1 = Odd axle counts rounded up if rounding enabled (Bit 1)

0 = Odd axle counts rounded down if rounding enabled (**default**)

SV 16: OK Message Control

Description: Turns **OK Message** components on/off with individual bits.

See **SV 20-F8** below for related information.

Default Value: 10011111

Bit 7	6	5	4	3	2	1	Bit 0
OK Msg	Rsrvd	Dir Sense	Axle	Speed	Length	Temp	Close

Bit 7 OK Message Enable

- 1 = OK Message spoken (**default**)
- 0 = OK Message not spoken

Bit 6 Reserved (ignored)

Bit 5 SDO Direction Sense – SDO Only (Ignored in **DDO** and **CZO**)

- 1 = OK Header, Greeting, Close 2 spoken if “S” Axle Sensor triggers first
- 0 = Header, Greeting, & Close 1 are always spoken in **SDO** (**default**)

Bit 4 Axle Count

- 1 = Axle Count spoken in message trailer (**default**)
- 0 = Axle Count not spoken in message trailer

Bit 3 Train Speed – SDO Only (Ignored in **DDO** and **CZO**)

- 1 = Train Speed spoken in message trailer (**default**)
- 0 = Train Speed not spoken in message trailer

Bit 2 Train Length – SDO Only (Ignored in **DDO** and **CZO**)

- 1 = Train Length spoken in message trailer (**default**)
- 0 = Train Length not spoken in message trailer

Bit 1 Temperature

- 1 = Temperature spoken in message trailer (**default**)
- 0 = Temperature not spoken in message trailer

Bit 0 Close Statement

- 1 = Close statement spoken in message trailer (**default**)
- 0 = Close statement not spoken in message trailer

SV 17: Defect Message Control

Description: Turns **Defect Message** components on/off with individual bits.

See **SV 40-E9** below for related information.

Default Value: 00010001

Bit 7	6	5	4	3	2	1	Bit 0
Reserved	Dir Sense	First	Repeat	EOT	Temp	Close	

Bit 7-6 Reserved (ignored)

Bit 5 SDO Direction Sense – SDO Only (Ignored in **DDO** and **CZO**)

- 1 = Defect Header 2 spoken when “S” Axle Sensor triggers first
- 0 = Defect Header 1 is always spoken in **SDO** (**default**)

Bit 4 “First” Always Spoken Before First Defect

- 1 = Report always numbers defects beginning with “First” (**default**)
- 0 = Defect report only numbers defects if more than one for a train

Bit 3 Repeat Defect Report

- 1 = Defect report and ending (if any) spoken twice in message body
- 0 = Defect report and ending spoken only once (**default**)

Bit 2 Defects Counted from End of Train

- 1 = Count defects from end of train
- 0 = Count defects from head of train (**default**)

Bit 1 Temperature

- 1 = Temperature spoken in message trailer
- 0 = Temperature not spoken in message trailer (**default**)

Bit 0 Close Statement

- 1 = Close statement spoken in message trailer (**default**)
- 0 = Close statement not spoken in message trailer

SV 18: Control 2

Description: Defines miscellaneous control values with individual bits.

Default Value: 01111110

Bit 7	6	5	4	3	2	1	Bit 0
Mute Err	Malfunc	Static	Greet	Short	Slang	RR Dir	Mute

Bit 7 Mute Error Messages

- 1 = Error messages unspoken (See **Section 7.6**)
- 0 = Error messages spoken (**default**)

Bit 6 “Malfunction” Spoken for Errors

- 1 = “Malfunction” spoken for error messages (**default**)
- 0 = “Integrity Error” spoken for error messages

Bit 5 Static Radio Bursts

- 1 = Static bursts before and after auto voice messages (**default**)
- 0 = No static bursts for automated voice messages

Bit 4 Greeting Message upon Train Detection

- 1 = Greeting spoken when train is first detected (**default**)
- 0 = Greeting not spoken when train is first detected

Bit 3 Short Greeting Message Select

- 1 = Short Greeting (SV 91 – 99 or F0 – F8) spoken as greeting (**default**)
- 0 = OK Header (SV 20 – 39 or A0 – B9) spoken as greeting

Bit 2 Crew Slang Enable

- 1 = Railroad slang enabled in Train Crew reports (**default**)
- 0 = Railroad slang disabled in Train Crew reports

Bit 1 Railroad Direction

- 1 = East/West railroad (**default**)
- 0 = North/South railroad

Bit 0 Mute All



- 1 = Sound disabled (recommended for visual display only choice)
- 0 = Sound enabled (**default**)

SV 20 – G3: Custom Automated Message SVs

Description: A message will play after a train passes a Defect Detector operating in Automated Trackside Voice Report mode. A **Greeting Message** on train detection can also be played. You can customize the messages your Defect Detector plays.

Messages are a mix of user-programmed segments and Detector-generated reports. Separate words and phrases are programmed into the message segments with these 144 SVs.

There are two message types: an **OK Message** for trains with no defects, and a **Defect Message** for trains with defects. Each message first plays its Header, then Body, and finally Trailer. The SVs relate to messages as shown here (Detector-generated reports are in gray):



Notice that a **Defect Message** is simpler and has fewer user-programmed segments than an **OK Message**.

Valid Values: 0 – FF

Method: Enter values into SVs from the **Word/Phrase Table (Section 10)**, beginning with the first SV for the segment. If all available segment values are not filled, enter “FF” in the first unused SV – the Defect Detector will fill in “FF” for the remaining unused SV values. (“FF” indicates an empty value.)

Example: If you program values in SV 20 – SV 39 thus:

SV	20	21	22	23	24	25	26	27	28	29
Value	D	18	1	17	11	0	4E	2C	2F	26
SV	30	31	32	33	34	35	36	37	38	39
Value	23	61	51	2F	FF	FF	FF	FF	FF	FF

You will hear the following **OK Message Header**:

A T AND S F RAILROAD, MILEPOST 3 2 POINT 4, TRACK NUMBER TWO

Here are the Automated Message SVs and their defaults:

SV 20 – 39: OK Header 1

SVs	Message Type	Segment	Number of Values
20 – 39	OK	Header	20

Default Values: DEFECT DETECTOR

SV	20	21	22	23	24	25	26	27	28	29
Value	44	46	FF	FF	FF	FF	FF	FF	FF	FF
SV	30	31	32	33	34	35	36	37	38	39
Value	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF

SV 40 – 69: Defect Header 1

SVs	Message Type	Segment	Number of Values
40 – 69	Defect	Header	30

Default Values: DEFECT DETECTOR BEEP STOP TRAIN BEEP

SV	40	41	42	43	44	45	46	47	48	49
Value	44	46	3E	5E	62	3E	FF	FF	FF	FF
SV	50	51	52	53	54	55	56	57	58	59
Value	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF
SV	60	61	62	63	64	65	66	67	68	69
Value	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF

SV 70 – 74: OK Body

SVs	Message Type	Segment	Number of Values
70 – 74	OK	Body	5

Default Values: NO DEFECTS

SV	70	71	72	73	74
Value	3A	FF	FF	FF	FF

SV 75 – 77: Axle

SVs	Message Type	Segment	Number of Values
75 – 77	OK	Trailer	3

Default Values: TOTAL AXLE COUNT

SV	75	76	77
Value	60	41	43

SV 78 – 79: Speed – Lead

SDO Only

SVs	Message Type	Segment	Number of Values
78 – 79	OK	Trailer	2

Default Values: TRAIN SPEED

SV	78	79
Value	62	5D

SV 80 – 82: Speed – Follow

SDO Only

SVs	Message Type	Segment	Number of Values
80 – 82	OK	Header	3

Default Values: (empty)

SV	80	81	82
Value	FF	FF	FF

SV 83 – 84: Length

SDO Only

SVs	Message Type	Segment	Number of Values
83 – 84	OK	Trailer	2

Default Values: TRAIN LENGTH

SV	83	84
Value	62	4B

SV 85 – 89: Close 1

SVs	Message Type	Segment	Number of Values
85 – 89	Both	Trailer	5

Default Values: END_OF_TRANSMISSION

SV	85	86	87	88	89
Value	3B	FF	FF	FF	FF

SV 90: Defect Ending

SVs	Message Type	Segment	Number of Values
90	Defect	Trailer	1

Default Values: (empty)

SV	90
Value	FF

SV 91 – 99: Short Greeting 1

SVs	Message Type	Segment	Number of Values
91 – 99	Greeting	Greeting	9

Default Values: DEFECT DETECTOR

SV	91	92	93	94	95	96	97	98	99
Value	44	46	FF	FF	FF	FF	FF	FF	FF

SV A0 – B9: OK Header 2

(Enabled in SDO by SV16, Bit 5)

SVs	Message Type	Segment	Number of Values
A0 – B9	OK	Header	20

Default Values: DEFECT DETECTOR TRACK TWO

SV	A0	A1	A2	A3	A4	A5	A6	A7	A8	A9
Value	44	46	61	2F	FF	FF	FF	FF	FF	FF
SV	B0	B1	B2	B3	B4	B5	B6	B7	B8	B9
Value	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF

SV C0 – E9: Defect Header 2

(Enabled in SDO by SV17, Bit 5)

SVs	Message Type	Segment	Number of Values
C0 – E9	Defect	Header	30

Default Values: DEFECT DETECTOR TRACK TWO BEEP STOP TRAIN BEEP

SV	C0	C1	C2	C3	C4	C5	C6	C7	C8	C9
Value	44	46	61	2F	3E	5E	62	3E	FF	FF
SV	D0	D1	D2	D3	D4	D5	D6	D7	D8	D9
Value	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF
SV	E0	E1	E2	E3	E4	E5	E6	E7	E8	E9
Value	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF

SV F0 – F8: Short Greeting 2

(Enabled in SDO by SV16, Bit 5)

SVs	Message Type	Segment	Number of Values
F0 – F8	Greeting	Greeting	9

Default Values: DEFECT DETECTOR TWO

SV	F0	F1	F2	F3	F4	F5	F6	F7	F8
Value	44	46	2F	FF	FF	FF	FF	FF	FF

SV F9 – G3: Close 2

(Enabled in SDO by SV16, Bit 5)

SVs	Message Type	Segment	Number of Values
F9 – G3	Both	Trailer	5

Default Values: DETECTOR TWO END_OF_TRANSMISSION

SV	F9	G0	G1	G2	G3
Value	46	2F	3B	FF	FF

10. Word & Phrase Table

Word or Phrase	Value
A	D
B	E
C	F
D	2
E	10
F	11
G	3
H	4
I	12
J	13
K	14
L	15
M	5
N	6
O	7
P	16
Q	8
R	9
S	17
T	18
U	B
V	19
W	C
X	1A
Y	1B
Z	1C
ZERO	30
ONE	25
TWO	2F
THREE	2C
FOUR	23
FIVE	21
SIX	28
SEVEN	27
EIGHT	1E
NINE	24
TEN	2A
ELEVEN	1F
TWELVE	2D
THIRTEEN	35
FOURTEEN	32
FIFTEEN	20

Word or Phrase	Value
SIXTEEN	29
SEVENTEEN	34
EIGHTEEN	31
NINETEEN	33
TWENTY	2E
THIRTY	2B
FORTY	22
ALARM	40
AND	1
AXLE	41
AXLES	42
BEEP (TONE)	3E
CENTRAL	6A
CONRAIL	6B
COUNT	43
DEFECT	44
DEGREES	45
DETECTOR	46
DOT	1D
DRAGGING	47
EAST	48
EASTERN	6C
END_OF_TRANSMISSION	3B
EQUIPMENT	68
FIRST	49
FROM_END_OF_TRAIN	37
FROM_HEAD_OF_TRAIN	3C
GREAT	6D
HAVE_A_SAFE_DAY	38
HIGHCAR	36
HOTBOX	4A
LENGTH	4B
LOAD	4C
MAIN	4D
MILEPOST	4E
MILES_PER_HOUR	39
NEAR	4F
NEW_YORK	6E
NICKEL_PLATE	76
NO	78
NO_DEFECTS	3A
NORFOLK	6F

Word or Phrase	Value
NORTH	50
NORTHERN	70
NUMBER	51
OF	52
ON	53
OUT	54
OVER	55
PAUSE (SILENCE)	3D
PENN	71
PENNSYLVANIA	77
POINT	26
RAIL	56
RAILROAD	0
RAILWAY	A
REPEAT	57
SECOND	58
SHIFTED	59
SIDE	5A
SLIDING	5B

Word or Phrase	Value
SOUTH	5C
SOUTHERN	72
SPEED	5D
STOP	5E
STOP_YOUR_TRAIN	79
SYSTEM	73
TEMPERATURE	69
THIRD	5F
TOTAL	60
TRACK	61
TRAIN	62
WABASH	74
WEST	63
WESTERN	75
WHEEL	64
WHISTLE (TONE)	3F
WIDE	65
WORKING	66
YOUR	67

Support & Service

If you have problems with your **TrainBoss™ Defect Detector**, please consult our website www.bouldercreekengineering.com. If you need additional help, please contact us at support@bouldercreekengineering.com.

Your Defect Detector can be repaired with a charge for parts and labor. Please contact support@bouldercreekengineering.com for a cost estimate on non-warranty repairs before sending product to us.

Limited Warranty

Boulder Creek Engineering, LLC warrants its products to be free of defects in materials and workmanship for a period of **one (1) year** from the purchase date. Defective product received by Boulder Creek Engineering during the warranty period will be repaired or replaced at our option. You must pay shipping to and from Boulder Creek Engineering.

This warranty does not cover damage resulting from negligent installation, improper operation, or unauthorized repair or modification. Removal of the heat shrink voids this warranty. Boulder Creek Engineering makes no other warranty of any kind, expressed or implied. In no event shall Boulder Creek Engineering be liable for incidental or consequential damages.

For warranty service, please contact Boulder Creek Engineering for a Return Merchandise Authorization (RMA) number. Product must be shipped to Boulder Creek Engineering with dated proof of purchase (your receipt).



2525 Arapahoe Ave.
Suite E4-605
Boulder, CO 80302

(303) 443-5784
support@bouldercreekengineering.com

Please visit www.bouldercreekengineering.com to see all of our Model Railroad products:

- **TrainBoss™** Talking Defect Detectors
- **WeighStation™** Track Scales
- **BrassHat™** Recordable Sound Modules
- **BrassHat™** Announcers
- **HotShot™** Speedometers
- **NightScope™** Infrared Detectors



(Photo courtesy of John Parker)